



NOTE:
 IF HOLDOWN IS ATTACHED TO POST PRIOR TO SIP INSTALLATION, ONLY REMOVAL OF THE FOAM WILL BE REQUIRED AND THERE IS NO REASON TO REMOVE OSB FACING AS SHOWN HERE. SEE EPT-306A

CONTINUOUS TENSION /
 COMPRESSION POST IN
 END OF SHEAR WALL PER
 PLAN.

(2) 2X SPLINE BLOCKING FOR
 OSB ATTACHMENT. SEE EPT-205

FILL CAVITY WITH RIGID OR
 EXPANDABLE FOAM, REPLACE OSB.

FASTENERS PER
 HOLDOWN
 MANUFACTURER.

HOLDOWN
 ANCHOR PER PLAN

CONCRETE WALL OR SLAB

BOTTOM PLATE

TREATED SILL PLATE

N.T.S.

Rev: 12/10/2021

EPT -306

HDU TYPE HOLDOWN

